



What Goes Up

At the job site, there's no excuse for dropped objects. To start with, all lifting equipment should be certified, inspected and properly operated to help ensure dropped object incidents don't occur.

Workers should be fully harnessed when working at height (six feet or more by US construction standards) and not guarded by standard railing. It's critical that all elevated tools, parts and materials always be secured. In addition, once the job is finished, workers should double check to make certain no loose objects are left behind. And last but not least, a restricted area should always be established beneath suspended objects or work being performed at height.



Remember: "No task is so important that it be done at the risk of Safety."